

# MARATHON PRODUCTS

# microDL-80C™

*Record and Log Ultra-low Temperatures in Shipments, Refrigerators or Freezers*



Our multi-use microDL-80C digital display technology now operates at ultra-low temperatures of -80°C (-112°F). The compact, coin-sized unit with the external thermistor probe can now help you verify that internal temperatures of your dry ice packages meet specifications prior to acceptance of your shipment. Simply push the start button to view critical temperature information upon arrivals. With optional memory sizes of 8k, 32k and 64k, accuracy and resolution of 0.5°C, and a one meter long flexible ribbon probe this product is the answer for data logging ultra low temperature freezers or dry ice shipments.

**Flexible** - Pressing the button will display the following visual information: whether or not the logger is Recording, the Current Temperature, Elapsed Time in Days, MKT (Mean Kinetic Temperature), High Temperature, Low Temperature, Alarm Time Over High Temperature, Alarm Time Below Low Temperature and Alarm Conditions. Customizable settings include: Delay to Start, Stop, Elapsed Time as well as customizable sampling time intervals. Also available: User Descriptions for initialization and for downloading the data.

**Visual Alarms** - All our data loggers have the ability to program alarm limits. Should the temperature reach levels outside these limits, the digital display will show a notice until reset by the user.

**Computer Ready** - You can download the recording to your PC and plot the data, at any time. Our proprietary microDL USB Reader is needed to download temperature information to a computer. Marathon's easy-to-use MDAS-Pro software is available for PCs running Microsoft Windows XP, Vista, 7, 8 and 10. 21CFR compliant software is available with full database capabilities.



### Temperature Range

-80°C to 30°C

### Temperature Accuracy

(NIST traceable)

±0.5°C at zero degrees

±1.0°C at extremes

### Measurement intervals

2 seconds to months

### EEPROM Memory

8k to 64k

# MARATHON



# PRODUCTS, INC.


*Don't ship without us!®*

# microDL-80C Specifications

Measurement Intervals	User programmable from 2 seconds to months
Power Source	(2) 3 volt lithium coin cells, IATA - FAA Compliant. 10 year shelf life with approx. 3 year continuous operating mode.
Alarm Limits	High & Low Alarms set by temperature and time
Size	Diameter: 2.86 cm (1.25 in.), Height: 1.4 cm (0.5 in.)
Water-resistant	Product package hermetically sealed to an IP66 rating.
Reader Station	USB 1.1 Port Interface
Software Compatibility	Windows XP, Vista, 7, 8 and 10
Sensor	Nist-traceable Thermistor
FAA/CE Compliance	RTCA/D-160 Ver. D, Section 21, Category H. / CE Marking


SKU number Model Name	8058 FP mdl8	8035 mdl32	8051 w/FP mdl64
EEPROM Memory	8K	32K	64K (variable)
Temperature Range			
Low / High	-80°C / 30°C -112°F / 86°F	-80°C / 30°C -112°F / 86°F	-80°C / 30°C -112°F / 86°F
Temperature Accuracy			
At zero	0.5°C / 1.0°F	0.5°C / 1.0°F	0.5°C / 1.0°F
Extremes	1.0°C / 2.0°F	1.0°C / 2.0°F	1.0°C / 2.0°F
Features			
Stainless steel backs	Yes	Yes	Yes
Variable memory	No	No	Yes
Continuous memory	Yes	Yes	Yes
Weight	17 g (0.6 oz.)	17 g (0.6 oz.)	17 g (0.6 oz.)
Mean Kinetic Temp.	Yes	Yes	Yes
Warranty	12 months	12 months	24 months

# Probe Options




### DISPLAY EXAMPLES


Press the Start button to see the following information display with each press:




**1. REC: 8.6°C**  
shows recording and current temperature




**2. RUN: 11 D**  
shows elapsed time in days




**3. MKT: 9.1°C**  
shows mean kinetic temperature (available on silver model only)




**4. HI: 15.2°C**  
shows alarm has occurred and high temperature




**5. LOW: 8.2°C**  
shows alarm has occurred and low temperature



**6. HI HR: 0.3**  
shows alarm time hours over high threshold



**7. LOW HR: 1.1**  
shows alarm time hours over low threshold



**8. REC: 14.9°C**  
Push to return to current temperature

Standard Stainless Steel Probe, SKU #8065 SP	
Length	15.24 cm (6 in.) or custom lengths
Diameter	3.49 mm (0.136 in.)
Micro Stainless Steel Probe, SKU #8061 MP	
Length	7.06 cm (2.78 in.) or custom lengths
Diameter	1.8 mm (0.07 in.)
Flat Flex Probe, SKU #8060 FP	
Length	61 cm (24 in.) or custom lengths
Width	0.76 cm (0.3 in.)
Detachable Flat Flex Probe, SKU #8074 RJ11	
Length	Custom Lengths
Width	0.76 cm (0.3 in.)
Flexible Teflon Probe with Stainless Steel Tip, SKU #8105 FTP	
Total Length	50.8 cm (20 in.) or custom lengths
Stainless Steel Tip	15.24 cm (6 in.)
Diameter	3.49 mm (0.136 in.)

Also available in standard temperature (-10°C to -40°C) and cryogenic (-200°C) configurations.

**Please call 1-510-562-6450**  
for more information or to place an order.  
[www.marathonproducts.com](http://www.marathonproducts.com)

14500 Doolittle Drive, San Leandro, CA 94577 ▪ sales@marathonproducts.com  
Specifications subject to change without prior notice.